

# 港鐵列車生活電子時計 MTR Train Digital Alarm Clock

## 產品規格及包裝資料 Product Specification and Packing Details

### 1. 包裝尺寸及內容 Packing Size & Contents:


<b>Island Line Train Digital Alarm Clock</b> 生活電子時計-港島綫	<b>Airport Express Train Digital Alarm Clock</b> 生活電子時計-機場快綫
 <p>產品尺寸 <b>Product size:</b> 11cm x 3cm x 3.6cm</p> <ul style="list-style-type: none"><li>- 生活電子時計 Train Digital Alarm Clock x 1</li><li>- AAA 鹼性電池 Alkaline Battery x 2</li><li>- 說明書 User Manual x 1</li></ul>	 <p>產品尺寸 <b>Product size:</b> 11cm x 3cm x 3.6cm</p> <ul style="list-style-type: none"><li>- 生活電子時計 Train Digital Alarm Clock x 1</li><li>- AAA 鹼性電池 Alkaline Battery x 2</li><li>- 說明書 User Manual x 1</li></ul>

### 2. 產品資料 Specifications:


<b>主要功能</b> <b>Main Function:</b>	<ul style="list-style-type: none"><li>- 12/24 時制顯示切換 12/24 Hour Time Display</li><li>- 全自動日曆 Calendar</li><li>- 每日定時鬧鈴 Daily Alarm</li><li>- 重鬧功能 Snooze Function</li><li>- LED 背燈功能(藍色) LED Backlight (Blue)</li><li>- 倒數計時器功能 Countdown Timer Function</li></ul>
<b>物料</b> <b>Material:</b>	<ul style="list-style-type: none"><li>- ABS 塑膠</li></ul>
<b>電池</b> <b>Battery:</b>	<ul style="list-style-type: none"><li>- AAA 鹼性電池 Alkaline Battery x 2 (包裝盒內附 included in pack)</li></ul>

主要功能圖  
標顯示位置  
及按鈕位置  
簡圖


Position of  
Main  
Function  
Icons  
Display &  
Function  
Buttons :




- A1 : 倒數計時器模式
- A2 : 鬧鈴模式
- A3 : 重鬧功能開啟指示符號
- A4 : 鬧鈴功能開啟指示符號
- A5 : LED背燈/ 重鬧功能鍵
- A6 : 全自動日曆
- A7 : 時間
- A8 : 星期



- B1 : 「向上」鍵
- B2 : 「向下」鍵
- B3 : 「模式」鍵
- B4 : 電池蓋
- B5 : 「設定」鍵
- B6 : 「計時」鍵



- A1: Countdown Timer Mode Indicator
- A2: Alarm Mode Indicator
- A3: Snooze on Indicator
- A4: Alarm on Indicator
- A5: LIGHT/ SNOOZE Button
- A6: Calendar
- A7: Time
- A8: Day of Week



- B1: UP Button
- B2: DOWN Button
- B3: MODE Button
- B4: Battery Cover
- B5: SET Button
- B6: TIMER Button